







Development and Qualification of a Fiber Optic Sensor Package for ITk Environmental Monitoring

Doomnull Attah Unwuchola

(University of the Western Cape)











OUTLINE



MOTIVATION

• THEORY, ANALYSIS AND RESULTS

CONCLUSION AND FUTURE WORKS

BACKUP









MOTIVATION



ATLAS Inner Tracker (ITk) upgrade at High Luminosity LHC for mid 2030 commissioning:

- Water condensation damages expensive detector electronics.
 - Humidity and temperature must be monitored to assess DewPoint temperature
 - Sensors must survive harsh conditions: high radiation, low temperature & low humidity (<10%)

Parameter	Value
Accuracy	ε _{RH} < 3.5% (between 0 and 10% RH) ε _{RH} < 10% (above 10% RH)
Precision	_{σRH} < 1.7 % (between 0 and 10% RH), _{σRH} < 5 % (above 10% RH)







Motivation



- Solution: Fiber Optic Sensors (FOS) technology based on Long Period Grating (LPG) and Fiber Bragg Grating (FBG) have been combined to provide a remarkable sensing device.
 - Requires extensive sensor R&D with tests under irradiation.
 - Software development in data acquisition (DAQ).
- Presented is the QA/QC done on FOS package at 25°C.
 - Preliminary checks on the T-sensitive FBGs in comparison to a T reference sensor.
 - Analyses on the Pre-Irradiation, Irradiation, and Post-Irradiation.
 - Investigation on the T-sensitive FBGs with the LPG/reference sensor readouts as the baseline.








ATLAS ITK LAYOUT













THEORY, ANALYSIS AND RESULTS









FOS sensing method




A FOS package with three sensors allows us to measure:


- Relative Humidity (RH)
- Temperature
- Radiation dose


Final Product

- Neo-ceram housing.
- Integrated Pt10k + HIH sensors.
- Pcb grounding solution.
- PEEK wire used to connect commercial sensors.

















FOS Calibration: T and RH


For T and RH calibration, the custom-built climatic chamber conditions are measured.


- FOS calibrated against standard commercial sensors.
 - Pt10k for temperature.

$$(t, \lambda_{FOS}) \& (t, T_{pt10k}) \longrightarrow (T, \lambda_{FOS})$$


• HIH for RH.

$$(t, \lambda_{FOS}) \& (t, RH_{HIH}) \longrightarrow (RH, \lambda_{FOS})$$









Climatic chamber setup used to calibrate fiber optic sensors











Investigation on Tresponse: FBGs vs. pt10k







Left: FBGs in the FOS package used in this analysis.

Right: FBGs in another companion FOS package with the same pt10k.

Due to the discrepancy, the ever-available pt10k temperature measurement was used in this analysis.








Characterization: T and RH on the LPG




 $\Delta\lambda$ [nm]


The set-up is used to regulate the T and RH to determine their thermo-hygrometric response.


- T characterization:
 - RH = constant,
 - T = varied by steps





- RH characterization:
 - T = constant,
 - RH = varied by steps





Used for calibration











RH raw spectra: Temperature compensated





$$rac{T_{
m pt10k}}{\left(rac{T}{\Delta\lambda}
ight)_{
m LPG}} = \Delta\lambda_{\Delta T_{
m LPG}}$$


$$\Delta \lambda_{
m raw} - \Delta \lambda_{\Delta T_{
m LPG}} = \Delta \lambda_{
m LPG_{
m RH}}$$






















Stable points used for RH Calibration curve



















FOS meets the specification before Irradiation



- FOS RH readout comparison to conventional sensor HIH (left plot)
- FOS almost exactly matches conventional sensor (left plot)
- Variance is within precision bounds (right plot)





RH over time - FOS vs HIH sensor

RH Variance: FOS readout minus HIH readout









Functionality under irradiation




Irradiation campaign at CERN IRRAD facility

• 24 GeV/c proton beam applies cumulative fluence of $7.56 \, X10^{15}\,$ protons per


cm² for 1 week.

Sensors still function after 2.06 MGy ionizing dose.

Sensor functionality survives radiation.



Change in response with increasing





Sensor mounted for irradiation at CERN'S IRRAD facility

Wavelength shift with increasing radiation dose











Characterization after Irradiation




- RH calibration curves of irradiated FOS at T = 25°C.
- Sensor still work after irradiation



Post-Irrad RH calibration curve



RH over time – FOS vs HIH sensor



RH Variance: FOS readout minus HIH readout











Calibration curves at different radiation dose.




 At different radiation dose, interpolation and extrapolation function acquired from real data-driven RH calibration curves



Real data



Interpolated function



Interpolated/extrapolated function at several dose exposure









Calibration curves at different radiation dose (live).




 At different radiation dose, interpolation and extrapolation function acquired from real data-driven RH calibration curves



Real data



Interpolated function (live movie)



Interpolated/extrapolated function at several dose exposure












RH Sensitivity: Pre-Irrad. & Post-Irrad.









Despite radiation dose exposure which diminished the sensitivity of the LPG sensor, it still works.











T-sensitive FBGs anomaly response



- Both FBGs are not supposed to be sensitive to both T and RH.
- Using the RH readout from the LPG and HIH sensors as baseline, the FBG spectra mimics their topology.
- For this particular FOS package, there appears to be cross sensitive and packaging effect problem.
- In discussion with the supplier of these FBG sensors












CONCLUSION AND FUTURE WORK.



- The QA/QC has been done a FOS package.
- With the pt10k ever available, any temperature anomaly measurement can be checked and corrected where necessary.
- FOS meets the specification before and after Irradiation.
- Some FOS packages have been delivered to ATLAS since July 2024
- Shown in the pictures are FOS packages installed in ITk Strips Barrels.

• More FOS packages have been requested, and new packages are being

assembled with QA/QC to be done on them.











THANK YOU













BACKUP












LPG T Calibration: Unchanged.












LPG-RH Variance: (FOS – HIH)readout



ΔRH [%]










ΔRH [%]

∆RH [%]

LPG-RH Variance: (FOS – HIH)readout



∆RH [%]









∆RH [%]